

# Parrot CK3300 with Nokia N90 and Wayfinder



Parrot





# Features

- GPS and Handsfree connection at the same time.
- Voice navigation instructions through car speakers.
- Automatic switch between GPS and phone applications for incoming calls.
- Voice navigation instructions are not played during a call.
- Automatic GPS connection.

## SetUp Procedures

- HandsFree Setup Procedure.
- GPS Setup Procedure.
- HandsFree & GPS connection at the same time

## Step 1 - HandsFree connection



CK3300's idle screen



Phone main screen

## Step 1 - HandsFree connection



Press Menu, and select the Connectivity icon



Select the Bluetooth icon



Make sure the Bluetooth is ON, then press on the right arrow of the phone


## Step 1 - HandsFree connection



Please enter in the  
OPTIONS menu



Select the NEW PAIRED  
DEVICE option



The phone will detect  
the Bluetooth devices

## Step 1 - HandsFree connection



Select your CK3300



Enter 1234 as PASSKEY



Accept the connection

## Step 2 : HandsFree disconnection



Select Parrot CK3300



Disconnect the phone  
and the CK3300

## Step 2 : HandsFree disconnection



The phone and the Parrot CK3300 are now disconnected

## Step 3 : GPS connection



Navigate to the Parrot CK3300  
GPS menu



Then click on  
**ACTIVATE / DEACTIVATE**

## Step 3 : GPS connection




Activate the carkit GPS function




From the phone, click on the  
WAYFINDER icon

## Step 3: GPS connection



WAYFINDER's start screen



Wayfinder is searching for Bluetooth devices

## Step 3: GPS connection



Select Parrot CK3300



Accept the carkit's GPS connection request

## Step 4 : HandsFree & GPS connection at the same time



HandsFree & GPS connection are activated at the same time  
(the GPS icon is displayed)

## Step 4 : HandsFree & GPS connection at the same time



Navigation using  
WAYFINDER

## Step 4 : HandsFree & GPS connection at the same time



Navigation using  
WAYFINDER