

# Parrot CK3300 with Symbian series 60 and Route 66



Parrot



[WWW.66.COM](http://WWW.66.COM)

# Features

- GPS and Handsfree connection at the same time.
- Voice navigation instructions through car front speakers.
- Automatic switch between GPS and phone applications.
- Mute of the car radio when voice navigations are played.
- Automatic GPS reconnection.

# SetUp Procedures

- HandsFree pairing.
- HandsFree disconnection.
- GPS connection.
- HandsFree & GPS connections at the same time.

## Step 1 - HandsFree connection



Select the Connectivity icon



Select the Bluetooth icon




The phone launch a search for new Bluetooth devices


## Step 1 - HandsFree connection



Select Parrot CK3300



Enter 1234 as PASSKEY



Accept the carkit's connection on the phone's display

## Step 2 : HandsFree disconnection



Select Parrot CK3300



Disconnect the phone  
and the CK3300

## Step 2 : HandsFree disconnection



The phone and the Parrot CK3300 are now disconnected

## Step 3 : GPS connection



Navigate to the Parrot CK3300  
GPS menu



Then click on  
**ACTIVATE / DEACTIVATE**

## Step 3 : GPS connection



Activate the carkit GPS function



From the phone, run Route 66 by clicking on the icon

## Step 3: GPS connection



Route 66's launch screen



Please select a Bluetooth  
GPS device

## Step 3: GPS connection




Route 66 is searching for  
Bluetooth devices




Select Parrot CK3300

## Step 3: GPS connection



Set Parrot CK3300 as the default GPS device



Accept the carkit's GPS connection request

## Step 4 : HandsFree & GPS connection at the same time



HandsFree & GPS connection are activated at the same time  
(the GPS icon is displayed)

## Step 4 : HandsFree & GPS connection at the same time



Navigation using Route 66